

M5 取扱説明書（英文版）

MUSIC BOXING

The generations of intelligent music boxing machines
Shenzhen Maitu Technology Co., Ltd.

CE RoHS FCC RECYCLE

MAITU

2000+ MUSIC P K AI

List of pack

Intelligent Music Boxing Machine boxing gloves boxing gloves Velcro

power adapter phone holder charging cable Dis-mounter

Notes: Some items may change with the change of the package, please refer to the pictures of the package actually purchased.

Button description

Horn

control buttons

Hit buttons

microphone

charging

marquee

Reset button
Ring light

⏮ previous song
⏪ Next song
⏩ volume Up
⏭ volume Down

1. power on: connect the USB interface of the machine to the adapter, press the middle button after powering on to automatically start the self-test, and the marquee and ring light will gradually light up and then go off during the self-test.
2. offline mode: After the machine self-check, if it is not connected to Bluetooth or APP, it will enter offline mode, and the built-in music of the boxing machine can be played through the control panel.
3. power off: Long press the power button to power off, and it will automatically standby if it is not operated for a long time.

Musical Boxing Machine Installation Guide

- choose a smooth and flat wall (make sure the wall is clean, dry, no dust), attach the velour to the wall, the top of the sticker is a little higher than eye level, no more than the user's head, and hold it for five minutes (pay attention to press it firmly with your hands).
- Attach the velvet surface on the back of the boxing machine to the velcro and press firmly on the body to make full contact.
- connect the charging cable of the device, and the machine will automatically turn on and self-check after powering on.

Remark: If the temperature is too high or too low, the viscosity may decrease. Please extend the fixing time to ten minutes.

Place the Velcro on a clean wall, the top of the sticker is at eye level

Press several times and let sit for 5 minutes

Attach the machine to the velcro

Press the machine and play a few songs

Musical boxing machine disassembly guide

- Loop the lanyard over your hands and press the rope firmly with your thumbs. Put your hands up to the machine.
- Row down along the hook and loop clearance position of the machine, first row one side and then row the other side.
- Grab the sides of the machine with both hands and take it down after the stroke is loose.

When tearing off the hook and loop, it is recommended to use 530 cleaner or alcohol to soften the colloid before tearing it off to avoid wall damage caused by violent operation.

Loop the lanyard over your hands

Cut down from the top of the machine

Cross both sides and paddle down

When the equipment is loose, grab it with both hands and take it off

APP download and connection

- Download by scanning the QR Code or searching for **MATUBOX** in the App store, currently supports IOS, ANDROID, HarmonyOS, TABLET, etc.
- Install and agree to the permissions required by the software in turn.
- open the APP and register and log in under the guidance of the APP.
- press and hold the power button of the boxing machine to power on, click the connection button on the APP Workout page, and select **MAITUBOX** to connect.
- Select **MAITUBOX MUSIC** connection in the Bluetooth list to start the sound playback function.
- select the song and click to start the workout (the new song will be automatically downloaded when clicked)

Equipment power indication

The middle light position of the 6 rake positions is the power indicator when it is idle.
The power level from low to high is:
low power medium and low power medium and high power full power
Make sure the device is fully charged before not using it for a long time.

guarantee card

This card is guaranteed, please keep it.

Model	smart boxing machine 5th generation		
Date of purchase		NO.	
Sales shop/Address			
Customer		Tel	
Address			

Passed ISO9001 international quality management system certification.

Model: smart boxing machine 5th generation
Inspector: QC PASS 01
Date of manufacture: _____

This product has been inspected and approved for shipment